


**OPERATING INSTRUCTIONS
AND
PARTS LIST**



**READ CAREFULLY
BEFORE USING**

POWER MACHINERY LIMITED



148 East Third Avenue - Vancouver 10, Canada

Warranty

This is to Certify:

1. That the component parts of all P. M. Power Chain Saws are manufactured from the highest quality of materials obtainable.
2. That all parts have been carefully inspected before assembly.
3. That machines are assembled and checked by thoroughly experienced mechanics.
4. That each machine is run in on the testing bench for three (3) hours before shipment.
5. That each bar and chain is run in and inspected, and each motor dynamometer-tested for power.

We, Power Machinery Limited, manufacturers of P. M. Power Chain-Saws, warrant that all saws manufactured by us are free from defective parts, and we undertake to replace any parts which are defective, provided such defective parts are surrendered to us or to our agents within one month from the date of delivery of the power saw to the consuming purchaser.

POWER MACHINERY LIMITED,

M. MacKay

Managing Director

OPENING MESSAGE

The P.M. Woodboss is designed to give the owner lengthy, dependable service. However, machinery of any kind, regardless of how good it may be, must be looked after. Moving parts must be kept lubricated, lost or loose screws, nuts and bolts must be replaced or tightened. The machine must be kept clean.

This operating manual is supplied to give the owner information that will aid in keeping the Woodboss in productive operation at all times.

Read it carefully; study the illustrations and diagrams. Any points that arise and are not covered in the manual will be cheerfully answered by your dealer or by the factory.

SPECIFICATIONS

Motor—Single cylinder—2 cycle—air cooled.

Power—4 H.P. at 3800 R.P.M. (Normal Cutting Speed)
(B.B.H.P. 2.5).

Cylinder—Cast nickel grey iron.

Crankshaft—Forged and heat-treated. Alloy steel. Precision machined and ground.

Connecting Rod—Forged alloy steel—heat-treated. Bronze bearings.

Piston—2" Bore; 1¼" Stroke; Aluminum Alloy. Heat-treated.

Ignition—Flywheel type, high tension magneto with built-in blower. Well known standard make.

Carburetor—Float type—Standard make.

Lubrication—Mixed with gasoline.

Cylinder Head—Aluminum Alloy. Finned for extra cooling.

Main Bearings—Ball Bearing—Standard precision made.

Gasoline Tank—Cast Magnesium—1 quart capacity.

Net Weight—14 inch—35 lbs.; 20 inch—36 lbs.; 26 inch—37 lbs.

Guide Bar—Alloy Steel—Heat-treated.

Cutting Chain—Alloy Steel—Heat-treated.

General Construction—Cast magnesium used for all castings except cylinder block and those few pieces where hard-wearing bearing surfaces are required.

Starting Pulley—Automatic Recoil.

WARNING

This 2-cycle engine depends for its lubrication upon oil thoroughly mixed with the gasoline in proper proportion and free from water. For filling of tank, a chamois or funnel with fine screen should be used. Never under any condition put gasoline in tank without first mixing it with oil. Make certain it is well mixed and in the proper quantity. One pint of S.A.E. 40 or 50 oil to each gallon of gas. This is the only way of lubricating piston, rings, cylinder walls, connecting rod and bearings.

See that your reserve supply of fuel is mixed in advance.

Starting a New Machine:

The machine, when it leaves our factory, is properly adjusted for steady running: it is possible, however, that rough handling in transit may result in mal-adjustment. In starting a new machine, therefore:

1. Check the machine over thoroughly, making sure nothing has been broken or damaged in transit.
2. Check cutting chain to make sure it is neither too loose nor too tight. It should be slightly slack to prevent burning the rounded part of the guide bar and to reduce friction. It should be possible to lift chain $\frac{1}{2}$ inch above centre of cutting bar with the fingers.
3. Fill the chain oiler in forward handle with light CLEAN lubricating oil and put some oil on the chain and in groove of the bar. When pitch is encountered, mix diesel or coal oil with the regular oil in chain oiler.
4. Adjust high speed jet (which is fitted with T handle) of carburetor until it is about one full turn open. Idling jet (which is knurled and slotted) seldom needs adjusting. It should be about $\frac{1}{2}$ turn open. Proper adjustment can be made only when motor is warm and when it is working.
5. Check clutch to make sure it is NOT engaged.
6. Make sure gasoline shut-off cock is in open position.
7. Open throttle by moving lever backward toward handle and give a quick pull on the starting handle.
8. Should the motor not start after two or three pulls it may be necessary to choke the carburetor. One or two pulls should be all that is necessary with the choke closed. As soon as motor fires, open the choke slightly, increasing the opening as the motor becomes warm.

Magneto Adjustment:

To remove flywheel from crankshaft unscrew right hand nut part way and tap nut with hammer to jar flywheel loose. Use piece of brass or hardwood to protect nut and shaft end. Set points at .018" to .020" gap.

To retard spark, loosen screws holding backplate assembly, turn magneto slightly in counter-clockwise rotation. To advance move in opposite direction.

KEEP THE MACHINE CLEAN: You will then be able to inspect parts more readily and detect looseness or breakage.

Crankshaft Assembly:

Should it be necessary at any time to remove the connecting-rod from the crankshaft, be careful when replacing it that the cap is put back in its proper position; identification marks are on the connecting-rod and cap for this purpose. Screws must be made as tight as possible. Be sure that lock-washers are securely locked.

Piston rings should have about .013" clearance between ends when fitted to cylinder-block.

Instructions for Felling:

To use the machine for felling, adjust the carburetor swivel collar (No. 129) so that the carburetor will swivel without having to loosen the collar or tighten it each time. At the same time it should be sufficiently tight so that it won't turn of its own accord. The pin screwed into the outside diameter of the collar is merely to facilitate turning it and is NOT a set screw.

Start motor in upright position, grip left hand on choke body of carburetor in preparation to turning it, place right hand on felling handle. With the left wrist stiff, and a good grip on the choke body, tilt the motor with right hand, allowing the grip to slip in the hand. The weight of the motor as it turns will actually swivel it on the carburetor with the result that it is in a felling position. Engage clutch and speed up motor as the chain starts to cut. When the bar is partly buried in cut, shift the right hand from the felling handle to the bucking handle so that more pressure can be put on the bar. Keep bar level to prevent a curved cut, resulting in the chain binding. The most simple way to gain practice in felling is to cut a few rings off the top of a stump. Practice getting the carburetor in the felling position when the motor is not running.

Maintenance of Cutting Chain:

The chain-saw does considerably more work than the hand-saw for the same period of time, and should be filed or ground at more frequent intervals. Whenever it is necessary to exert unusual pressure on the chain to make it cut it is

time the chain should be sharpened. A dull chain will wear more quickly and will require more time to sharpen, it will also, through the necessary pressure exerted to make it cut, cause excess wear on the edges of the guide bar and on the motor.

Filing Instructions:

Never, at any time (unless to correct serious damage to a portion or all of a chain), file a chain from the top, but **always** from the front of the tooth. Filing from the front extends the life of the chain and maintains adequate space between the teeth to hold sawdust while the chain is in the cut, actually the space increases as the chain is filed back. Should the teeth be filed from the top the space is decreased and the chain life shortened. **This is very important.**

Assembly of Connecting Rod and Piston

(See Diagram 8, Page 21)

Never hammer a wrist-pin into place while the piston is cold as there is too much danger of the piston being deformed. This also applies to dis-assembling.

If the piston is heated in boiling oil, preferably heavy oil, the wrist-pin bore will expand sufficiently so that the pin will drop in, or with very little tapping go into place.

Be sure lock rings for wrist-pin are firmly in place.

Should the piston be out of round after assembly it can be tapped into shape with a leather or plastic hammer, but care must be taken not to damage the ring grooves.

Be very sure when assembling the rod and piston that the oil hole in the cap of the rod is on the **opposite** side to the exhaust side of the piston. This will make the oil hole face the intake hole in the crankcase and insure lubrication.

Check connecting rod and piston for alignment and straighten rod if necessary.

Connecting rod bearings are replaceable. Be sure of proper location for crank-pin bearing. Lubrication holes in bearing and con rod cap must line up.

Connecting Rod

(Illustration Page 21)

When assembling connecting rod on the crankshaft, be sure marked ends of the cap and rod go together. Be certain screws are perfectly tight, and lockwashers are securely locked. Connecting rod bearing on crankshaft should have clearance of .0015. Too tight or too loose will cause serious trouble. The lubricating hole in bottom of con rod cap should face the fuel intake in crankcase.

Cylinder Head

Be sure when placing cylinder head on cylinder block that flow of air from flywheel fan will pass **between** cooling fins on cylinder head, not across fins. Retighten cylinder head nuts when motor has run $\frac{1}{2}$ hour after installing a new gasket.

Pitchy Wood

If cutting in "pitchy" wood, add some kerosene or diesel oil to the oil in chain lubricator.

CAUTION

Do not race your motor at high speed when not actually cutting. Warming it up slowly adds to the life and usefulness of your machine.

How to File and Joint Your Saw For Different Kinds of Woods

It can be understood why a chain saw filed and jointed for softwoods would not give best results in cutting frozen woods or hardwoods, and vice-versa. Consequently it can be understood why all saws leaving the factory must be filed and jointed to one particular standard. All saws leaving the factory are filed and jointed for softwood **unless ordered otherwise**.

This standard is called "No. 3 Chain" and is sharpened and jointed as follows:

| | Cutters | Off-set Rakers | Straight Center Rakers |
|--|--------------------|---------------------------|---------------------------|
| Top Bevel | 35° | 20° | None |
| Front Bevel | 5° | 20° | None |
| Hook | 5° negative | 20° positive | 20° positive |
| Jointing (Clearance between point of cutter and raker).... | all same height | .020 lower than cutter | .020 lower than cutter |

If you intend to use your saw to cut frozen wood or hard-wood it will be necessary for you to re-file and re-joint it, or order special chains.

If you want a chain for frozen woods order **Chain No. 3 for frozen wood** (No. 3-F.W.).

If you want a chain for hardwood such as oak, hickory, etc., order **Chain No. 3 for hardwood** (No. 3-H.W.).

If you wish to re-file or rejoint your own saw or have it done by a professional saw filer in your district, the following instructions should be carefully followed:

General Instructions


1. Careful filing will give a fast cutting chain.
2. The height of the teeth should be uniform.
3. Angles of teeth and clearance between points of the side cutters and rakers should be as given in specifications.
4. Keep your saw sharp. A dull saw is inefficient and it increases the wear on the cutter bar and motor.
5. Study diagram. Make sure you understand it. Note the bevel indicated by heavy black line is on the side of the cutter facing you. The bevel indicated by the dotted line is on the side of the cutter away from you.

How to Sharpen and Joint Your Saw For Hardwood and Frozen Wood

1. Make certain that all the center and offset raker teeth are uniform in height. (See "Instructions for use of Filing Vise" in Instruction Book.)
2. The front bevel of the offset rakers should be changed from 20° bevel (see standard specifications) to 10° bevel and the hook on all rakers from 20° positive to 10° positive. Front bevel on sidecutters from 5° to 0° (straight).

Filing Angles and Clearances for Hardwood and Frozen Wood

| | Cutters | Off-Set Rakers | Center Rakers |
|----------------------------|----------------------|-------------------------|-------------------------|
| Top Bevel | 35° | 20° | None |
| Front Bevel | 0° | 10° | None |
| Hook | 5° neg. (or less) | 10° | 10° |
| Jointing (clearance) | | .020" lower than cutter | .020" lower than cutter |



The instructions given for filing and jointing are our Standard specifications. You may find it necessary to vary these specifications slightly in order to get best results in your particular operation. Sawing conditions vary with type of wood, sap content, temperatures and localities.

This diagram will give an idea of the angles at which to file to obtain 10, 15 and 20 degree bevels.

DIAGRAM 2




DIAGRAM 3

Instructions for Use of Filing Vise, Setting Block, Cutter Gauge and Raker Gauge with Feeler




DIAGRAM 4

A—Filing Vise

B—Jointing Gauges—Raker and cutter

C—Setting Block

The Vise is made to firmly clamp a chain by the lugs at tightening of the handles "H". Three holes at the bottom of the vise can be used for fastening it to a bench or stand.


There are two jointing gauges and a .015" feeler required for the vise, one gauge stamped "C" is for use on the side-cutters, the other stamped "R" is for use on the rakers. Both slide along the back and top of the vise to gauge the heights of the teeth.

To joint a chain (the process of filing the cutters to equal heights and the rakers to equal heights, but .015" lower than the cutters), set the cutter gauge by adjusting the screw to the lowest side-cutter point, and file all other cutters on the tops until the points are of equal heights, then set the raker gauge so that the set-screw is .015" lower than the set-screw of the side-cutter gauge, file the tops of the rakers to correspond with the original angles making them .015" lower than the side-cutters.

The setting-block attachment is quite often not necessary for chain maintenance, but for some types of timber additional set may be required. When this is done it is necessary to set only the point of the side-cutters. This is accomplished by adjusting the chain in the vise so that the point of the tooth overlaps the beveled edge of the hardened portion of the setting block and striking the point of the tooth firmly with a small hammer. The point of the tooth will then be set out farther than the rest of the tooth. With practice, one strike of the hammer will be sufficient to set the tooth over. Care must be taken not to break the point of the tooth.

How to Order

The above 4 parts are priced separately. When ordering please state clearly whether you want the VISE ONLY or the COMPLETE SET of Vise with Gauges and Setting Block.



COMPLETE SERVICE PARTS LIST

WICO MAGNETO SPECIFICATION FW-2146

Starting at Serial No. D15000

| Part No. | No. per Unit | Part Name |
|----------|--------------|---|
| 2965 | 1 | Fixed contact clamp screw washer |
| 3219 | 1 | Breaker arm pivot washer |
| 4210 | 1 | Breaker arm lock |
| Y5423 | 1 | Rotor |
| 5536 | 1 | Primary lead wire clip screw |
| 6318 | 1 | Cam wiper felt |
| X6840 | 1 | Lead wire group |
| 7513 | 1 | Breaker cam |
| X7529 | 1 | Condenser group |
| 7533 | 1 | Condenser clamp screw (Sems) |
| 7533 | 1 | Fixed contact clamp screw (Sems) |
| 7533 | 1 | Condenser connection screw (Sems) |
| X7536 | 1 | Coil group |
| X7544 | 1 | Breaker contact set |
| X7643 | 1 | Stator plate unit (Includes stator plate, core, coil, condenser, lead wire and breaker mechanism and Magneto Backplate) |
| X7682 | 1 | Stator plate repl. assy (Includes stator plate and coil core and Magneto Backplate) |
| 10407 | as req. | Breaker point spacing washer |
| 250 | as req. | Complete Magneto |

Model FWS 18 WICO MAGNETO

On Models Prior to Ser. No. 15000

| Part No. | PART NAME |
|----------|--|
| Y 5423 F | Rotor |
| 5429 F | Cam |
| X 5342 F | Condenser |
| X 5345 F | Coil |
| X 5473 F | Stator Plate Assembly |
| X 5474 F | Fixed Contact |
| X 5474 F | Breaker Arm |
| 4210 F | Breaker Arm Lock |
| 3219 F | Breaker Arm Spacing Washer |
| 5411 F | Fixed Contact Clamp Screw |
| 5411 F | Condenser Clamp Screw |
| IXA-256 | Fixed Contact Clamp Screw Washer |
| 10407 F | Breaker Arm Spacing Washer |
| 5146 F | Cam Wiper Felt |
| 5077 F | Cam Wiper Felt |
| 10383 F | Coil Wedge |
| 5431 F | Breaker Spring Clamp Screw |

MD-44A CARBURETOR ASSEMBLY PARTS

(Using Tillotson MD-44A Model)

REPLACING MODEL AJ-13B

| Part No. | Description |
|----------|---|
| 230 | Breather Body |
| 231 | Carb. Toggle Adapt. |
| 232 | Throttle Rod |
| 233 | MD-44A Carburetor (c/w Pts. Nos. 231 and 234) |
| 234 | Toggle Rivet |
| 10235 | 1/8 I.P.S.x90° Street Elbow |
| 236 | Breather Screen (small) |
| 513(2) | 8/32x1/2 R.H.M.S. |
| 525(2) | No. 8 Shakeproof Washer |
| 129 | Swivel Collar |
| 185 | Swivel Collar Stud |
| 135 | Breather Screen (C/case Sc.) |
| 158 | Breather Clip Ring (Crankcase Clip Ring) |
| 128 | Carburetor Adapter |
| 146 | Carburetor Gasket |
| 10193(2) | Carburetor Studs |
| 132 | Intake Valve |
| 133 | Intake Valve Spring |
| 150(3) | Intake Valve Pins |
| 197 | Spring Retainer Bar |
| 157 | Throttle Lever |
| 196 | Throttle Lever Washer |
| 179 | Throttle Tension Spring |
| 260 | Copper Mesh |
| 504 | 12/24x7/8 R.H.M.S. |
| 503 | 12/24x1/2 R.H.M.S. |
| 537 | 6/32x1/2 R.H.M.S.—Reed Valve |
| 237 | Intake Pin Retainer |
| 236 | Breather Screen (Breather Body) |




DIAGRAM 6

Model AJ-13B TILLOTSON CARBURETOR

| Part No. | Part Name |
|----------|--------------------------------------|
| 07353 | Body |
| 02531 | Body Welsh Plug |
| 05591 | Flange Gasket |
| 04636 | Float |
| 05425 | Float Retaining Cotter Pin |
| 0164 | Float Bowl Drain Plug |
| 0648 | Float Bowl Drain Plug Gasket |
| 07216 | Float Bowl Cover |
| 07198 | Float Bowl Cover Gasket |
| 054 | Float Bowl Cover Screw |
| 0992 | Float Bowl Cover Screw Lockwasher |
| 06910 | Idle Adjustment Screw |
| 06243 | Idle Adjustment Screw Locknut |
| 0759 | Idle Adjustment Screw Lockwasher |
| 06905 | Idle Tube |
| 06569 | Idle Tube Gasket |
| 06941 | Inlet Valve and Seat |
| 0212 | Inlet Valve Seat Gasket |
| 02395 | Inlet Valve Channel Plug Screw |
| 04152 | Main Adjustment Screw |
| 0702 | Main Adjustment Screw Gland |
| 0676 | Main Adjustment Screw Gland Gasket |
| 0705 | Main Adjustment Screw Packing |
| 0703 | Main Adjustment Screw Packing Nut |
| 07385 | Throttle Shaft and Lever (Assembled) |
| 07369 | Throttle Shutter |
| 01462 | Throttle Shutter Screw |
| 01675 | Throttle Shutter Screw Lockwasher |
| 07231 | Gasket and Packing Set |

CARBURETOR INSTRUCTIONS

FLOAT SETTING

To check correctly separate Fuel Bowl Assembly from Upper Body Assembly and Gasket. (See Disassembly Instructions Nos. 1 and 2 below). Now with Fuel Bowl Assembly held in upside down position the then lowest point of float, at free end, should project $1/64"$ below rim of fuel bowl. If resetting is required remove Float (Disassembly Instruction No. 3) and slightly bend vertical float lever only to obtain proper measurement. When inspection indicates Fuel Lever continues to rise beyond float setting point, remove Inlet Needle and Seat. Clean their seating surfaces with a soft cloth. Place Inlet Needle in its seat and tap very lightly while turning Inlet Needle with thumb and forefinger several times to reseal. Re-install, then if proper fuel level is not maintained, install new Inlet Needle and Seat Assembly. **Do not change Float Setting from manufacturing specifications.**

ADJUSTMENT INSTRUCTIONS

Before starting engine check for proper fuel supply in tank. Open Fuel Line Shut Off Valve.

Separate manual carburetor adjustments are provided. Main Adjustment Screw (27) controlling power range mixture and Idle Adjustment Screw (19) governing idle mixture at closed throttle and Idle Speed Regulating Screw (21) controlling required idling speed.

INITIAL ADJUSTMENT

Completely close Idle Adjustment Screw (19) by turning in (clockwise) until seated (without forcing) then turn back in opposite direction about one and one-half ($1\frac{1}{2}$) turns. Proceed in like manner with Main Adjustment Screw (27) except open about one full turn after being first closed. Now choke and start engine in usual manner and run until thoroughly warm.

POWER RANGE ADJUSTMENT

With engine running at a constant speed of approximately $\frac{1}{2}$ open throttle position, slowly turn Main Adjustment Screw (27) inward (clockwise) until motor begins to lose speed, then slowly turn back in opposite direction (usually $\frac{1}{8}$ to $\frac{1}{4}$ of a turn) until maximum speed and power is obtained. This will be correct adjustment setting.

IDLE MIXTURE ADJUSTMENT

This adjustment should only be made **after** the above mentioned power range adjustment has been completed. Close throttle and allow engine to idle at slightly faster than normal idling speed requirements by turning Idle Speed Regulating

Screw (21) and located on throttle level, inward. Next, slowly turn Idle Adjustment Screw (19) inward (clockwise) until motor begins to lose speed and miss or flutter, then turn back in opposite direction (usually about $\frac{1}{8}$ of a turn) until engine functions smoothly and steadily. Now slowly back out Idle Speed Regulating Screw (21) until desired idling speed is obtained. This will be correct idle adjustment setting.

FINAL ADJUSTMENT

Alternately open and close throttle a few times for adjustment test. If acceleration hesitancy or stalling at idle speed occurs, entire adjustment procedure, outlined above, should be repeated. Preceding instructions cover cold motor start only.

Warm motor only requires opening of throttle and one or two vigorous pulls on starter rope without further carburetor adjustment. Regardless of altitude or climatic conditions a proper carburetor adjustment can be made by following the above rules — which eliminates jet changes.

CARBURETOR PARTS LIST

| Ref. No. | Part No. | PART NAME |
|----------|----------|---|
| 1 | 09093 | 1 Body upper half |
| 2 | *22531 | 1 Body Channel Welch Ring |
| 3 | 07903 | 1 Body Gasket |
| 4 | 06062 | 4 Body Retaining Screw and Lockwasher |
| 5 | *22534 | 1 Choke Friction Pin |
| 6 | *03860 | 1 Choke Friction Pin Spring |
| 7 | *07912 | 1 Choke Friction Pin Screw |
| 8 | 05566 | 1 Choke Lever |
| 9 | 03208 | 1 Choke Lever Retaining Pin |
| 10 | 07906 | 1 Choke Shaft |
| 11 | 03739 | 1 Choke Shutter |
| 12 | 05430 | 1 Choke Shutter Screw |
| 13 | 05591 | 1 Flange Gasket |
| 14 | 07804 | 1 Float |
| 15 | *07901 | 1 Float Lever Pinion Screw |
| 16 | 08332 | 1 Fuel Bowl |
| 17 | *03311 | 1 Fuel Bowl Drain Screw (small) |
| 18 | 07896 | 1 Fuel Bowl Plug Screw (large) |
| 19 | 06910 | 1 Idle Adjustment Screw |
| 20 | 05725 | 1 Idle Adjustment Screw Spring |
| 21 | 05095 | 1 Idle Speed Regulating Screw |
| 22 | 0788-A | 1 Idle Speed Regulating Screw Spring |
| 23 | 08515 | 1 Idle Tube |

Parts illustrated with reference numbers for identification only.

Please specify correct part number and name

| Ref. No. | Part No. | PART NAME |
|----------|----------|--|
| 24 | 07900 | Idle Tube Gasket |
| 25 | *07895 | Inlet Needle, Seat and Gasket |
| 26 | 02510 | Inlet Seat Gasket |
| 27 | *08160 | Main Adjustment Screw |
| 28 | 0702 | Main Adjustment Screw Gland |
| 29 | 0676 | Main Adjustment Screw Gland Gasket |
| 30 | 0705 | Main Adjustment Screw Packing |
| 31 | 0703 | Main Adjustment Screw Packing Nut |
| 32 | *08179 | Main Nozzle |
| 33 | 02395 | Main Nozzle Channel Plug Screw |
| 34 | 09092 | Throttle Shaft and Lever |
| 35 | *08647 | Throttle Shaft Return Spring |
| 36 | 08646 | Throttle Shutter |
| 37 | *05204 | Throttle Shutter Screw |
| 38 | *08598 | Throttle Stop Lever |
| 39 | 04594 | Throttle Stop Lever Pin |
| 40 | *06393 | Throttle Stop Lever Screw |
| 41 | *06396 | Throttle Stop Lever Screw Lockwasher |
| 42 | *08025 | Gasket and Packing Set |
| 43 | 08750 | Repair Parts Kit |
| | | PARTIAL ASSEMBLY |
| | 09091 | Choke Shaft and Lever |

* Indicates Contents of Repair Parts Kit.

HOW TO DISASSEMBLE FOR CLEANING OR REPAIR

To correctly disassemble, the following parts must be removed separately and in order indicated:

- (1) Complete Main Adjustment Screw (27) and Gland Assembly from Bowl;
- (2) Body retaining screws and lockwashers, to separate Upper Body and Fuel Bowl assemblies;
- (3) Float Lever Pinion Pin and Float (14) from Fuel Bowl;
- (4) Large Plug Screw (18), the Inlet Needle (25) and Gasket Assembly from Fuel Bowl;
- (5) Idle Adjustment Screw (19) Spring, Idle Tube (23) and Gasket, also Main Nozzle Channel Plug Screw (33) from Upper Body;
- (6) Throttle Shutter (36) Shaft and Lever Assembly.

To reassemble, reverse the above instructions when installing parts indicated.

DISMANTLING

There are various procedures to follow to simplify dismantling. We suggest that the following procedure, if followed, will prove to be the most satisfactory.

1. **Strut and Oiler**

Remove the strut and felling handle, guide bar and chain. This is done simply by unscrewing the three nuts (No. 511) and pulling off the assembly. This will eliminate considerable weight and simplify handling of the remaining unit.

2. **Gas Tank**

There are six (6) screws (No. 503) securing the gas tank (No. 126) to the ventilator housing (No. 125) which must be taken out before removing the tank. To prevent the loss of any gas which might remain in the tank, turn off shut-off cock (No. 266) and uncouple fuel line (No. 258).

3. **Carburetor Assembly**

Unscrew the swivel collar stud (No. 185) and uncouple swivel collar (No. 129), noting the gasket (No. 151) between crankcase (No. D-105) and carburetor adaptor (No. 128), which must be replaced at re-assembly.

4. **Flywheel and Magneto**

Remove blower housing cover (No. 168). Occasionally it is necessary to jar the magneto flywheel free from the crankshaft. This is done by backing off the flywheel nut (R.H. No. 515) one thread beyond the end of the shaft, so that the sharp blow from a soft hammer (brass hammer) required to free the flywheel will in no way damage the crankshaft end.

The key (No. 535) holding the cam and flywheel to the shaft must be taken out before removing the magneto backplate. It is **important** to note position of spring washer (No. 187) between flywheel and cam. Removal of magneto backplate is done by disconnecting the wire (No. 275) from the shorting button (No. 273) and unscrewing and removing the two screws holding the backplate to the crankcase. Pull the high tension wire from the spark plug through the hole in the blower housing (No. 125) after removing clip, and slip unit over end of crankshaft, taking extreme care not to damage the fibre rubbing block. After ventilator housing has been removed, pry cam free with two screw drivers.

5. **Ventilator Housing and Handle Bars**

Unscrew remaining three nuts from studs on inside of blower housing. Remove blower housing. From the starting pulley side, pull completely free the two bolts (No. 175) and remove handlebars (No. 156).

6. **Cylinder Block and Piston and Connecting Rod Assembly**

To remove cylinder block (No. A-102), simply unscrew the four (1/4-28) nuts holding it to the crankcase and lift over piston. Remove exhaust stack (No. D-124) and clean out all carbon before re-assembly.

To remove connecting rod, unscrew the two screws holding the connecting rod cap in place on the crankshaft. After removal, re-assemble parts to prevent losing. Refer to connecting rod replacement instructions for re-assembly with crankshaft.

7. **Clutch Cover and Clutch Fork**

Remove clutch cover (D-118) by prying off with two screw drivers. Release locking washer (D-227) and unscrew clutch nut (D-553). Pull off thrust bearing retainer (D-226). Remove (D-119) and (D-169) toggle pins. The fork (D-17) is now free and can be removed by drawing the clutch control rod down through the opening in the upper part of the clutch housing.

8. **Chain Cover**

Remove starting pulley assembly (A-322) (follow starting pulley instructions). Next remove the nine No. 8-32 screws (No. 501) which hold the crankcase cover (D-107) and chain cover (D-106) together. It will be noted from diagram No. 2 all that remains now to free chain cover is the bearing fit on the crankshaft. It is necessary to put screw drivers between crankcase cover and chain cover and pry them apart, at the same time removing the bearing from the shaft.

9. **Clutch Assembly, Roller Chain and Small Sprocket**

To dismantle roller chain, locate connecting link and remove. Re-assemble parts after removal to prevent loss. Some roller chains will have no connecting link, in which case a link can be found that has been riveted at assembly. File away flared portion of rivet heads and pry apart. Care must be taken not to file away too much of the rivet head so that it cannot be re-riveted.

Before removing sprocket shaft and clutch assembly from crankcase cover (D-107) detach the cutting chain sprocket (No. 153) from sprocket shaft. This screws on the shaft and has a right hand thread, so that removal will often require a sharp blow on the ends of the teeth with a soft hammer to jar it loose.

Once the sprocket is removed push the whole assembly free by tapping on the sprocket end of the shaft with a soft hammer. Be sure not to damage the threads of the sprocket shaft.

Use a puller to remove sprocket (A-108), taking care not to lose woodruff driving key (No. 528) that locates it on the shaft.

10. Crankcase

Holding crankcase in the left hand and using a soft hammer, tap crankshaft on magneto end to free bearing and shaft from crankcase. Do not hit the crankshaft too hard, otherwise the shaft may be forced out of line, or the threads may be damaged. If the assembly is an extremely tight fit it may be necessary to heat the crankcase in order to dismantle these parts. A blow-torch may be used for this purpose, but it will not be necessary to apply a great amount of heat.

11. Crankshaft

Use a soft hammer to drive crankshaft (A-101) free from crankcase cover (D-107).

12. Grease Seals

When removing grease seals (No. 253) from crankcase (D-105) and crankcase cover (D-107) use a sleeve or piece of metal close to the outside diameter of the seal to drive them from the castings. Be sure not to damage the fabric of the seal when removing. **Should seals be at all damaged they must be replaced.**

13. Grease Seal Bushings

Grease seal bushings can be removed from the crankshaft by prying them loose with a screw driver after removing woodruff key. Bearings can also be removed in this manner, but care must be taken not to damage the shielded portion when doing this.

14. Dismantling Carburetor Assembly

It should be necessary to dismantle carburetor (No. 251) only for cleansing purposes, and then only to remove the air filter screens and packing. Clean thoroughly in gasoline. The rest of the unit can be cleansed thoroughly in gasoline without any further dismantling.

15. Dismantling Clutch Assembly

Clean thoroughly in gasoline before preparing to dismantle, then inspect thoroughly, checking freedom of bearings, etc. Should everything appear in order no further dismantling should be undertaken.

Should there be any apparent wear making dismantling necessary simply remove cotter pins from the four nuts compressing the clutch springs and take off nuts. When removing the clutch plates, note their order of assembly so that they can be replaced the same way.

RE-ASSEMBLY

In general, the procedure to follow in re-assembling is the reverse of the steps taken in dismantling. While doing this, there are certain points to BEAR IN MIND which are described below.

1. In pressing bearings (No. 255) on crankshaft (A-101) be sure that the shaft is not forced out of alignment.
2. Always use "Permatex" or any other gasket compound on the gasket face of the crankcase when assembling to crankcase cover. If possible, heat crankcase for ease in fitting the crankshaft bearing.
3. Note the position of the grease seals (No. 253) when pressing into the crankcase and cover. The fabric of the seal **must** be turned in to hold crankcase compression. The grease seal bushings are inserted **after** the seals so as not to damage the sealing fabric.
4. After assembling the drive (the small sprocket, the clutch and roller chain) and packing it with grease, put on the chain cover assembly, making sure that "Permatex" is applied to the gasket face in order to retain grease in the housing. At this time check all the toggles and pins for any sign of wear, and if so replace worn parts immediately.
5. On adjusting the clutch fork for correct clutch setting, apply grease to the clutch fork wearing surface so that wear on the bearing retainer is kept at a minimum. **Refer to instructions on clutch adjustment.**
6. When replacing starting pulley assembly tighten the left hand nut on crankshaft as much as possible. Doing this centralizes the crankshaft correctly in relation to the crankcase walls.
7. When re-assembling the connecting rod to the crankpin there are 3 points to note:
 - (a) The large flared part of the piston dome **MUST** face the front of the machine (exhaust side).
 - (b) Identification marks on rod and cap must be together for correct alignment. Place large bearing in correct position.
 - (c) Be sure that the connecting rod screws are tight and the connecting rod washers are securely clamped around the screws. **Use a heavy screw driver for tightening screws.**
8. When fitting cylinder block, make sure that the piston rings are located correctly by the rings in the groove, and that both block and piston are lubricated for ease in fitting. Fit piston rings to block, leaving .010" gap. Prior

to assembly check block to see if free from carbon deposits, and also install a new gasket between crankcase and cylinder block.

9. When assembling carburetor assembly check the reed valve spring to see that there is tension on the reed valve. This is necessary for maximum performance of the motor. Spring, when in position on spigot of retaining bridge (No. 197) should be 1/16" to 3/32" above the level of the two flat portions of the bridge.
10. When mounting magneto backplate to the crankcase, the approximately correct setting places the backplate in a vertical position. If the motor is sluggish and will not pick up speed, advance the spark by rotating the backplate in a clockwise direction. If the motor lacks power at low speeds, retard the spark by rotating in a counter-clockwise direction. When pressing the cam in place, note that the arrow on the cam is on the outside, and that it points in the direction of rotation of crankshaft (counter-clockwise). Check to see that the points are set at .020 gap.
11. Be sure the spring washer (No. 187) is in place (between cam and flywheel) before securing flywheel in place.
12. Prior to fitting the strut and oil tank, make sure that the cutting chain is correctly located on the cutting chain sprocket. The points of the sprocket MUST fit between the links of the chain. Be sure chain tightener is correctly located on sawdust raker.
13. After motor has been re-assembled and properly run-in, remove gas tank and tighten cylinder head screws and cylinder block nuts.

HARDWARE for WOODBOSS Power Chain Saw

| Part No. | Qty. | Description | Position |
|----------|------|----------------------------------|-----------------------------|
| 500 | 1 | 12/24 x 5/8 R.H.M.S. | Exhaust |
| 501 | 9 | 8/32 x 1/4 R.H.M.S. | Chain Case |
| 503 | 10 | 12/24 x 1/2 R.H.M.S. | Gas Tank and Throttle |
| 504 | 2 | 12/24 x 7/8 R.H.M.S. | Gas Tank and Throttle |
| 505 | 2 | 8/32 x 5/8 R.H.M.S. | Carburetor |
| 506 | 1 | 1/4-20 x 5/8 F.H.M.S. | Combination Nut |
| 507 | 1 | 5/16-18 x 1 1/4 Fillister H.M.S. | Chain Tightener |
| 508 | 2 | Special Conrod Screw | |
| 509 | 4 | 1/4-20 x 3/4 H.H.C.S. | Clutch Housing Cover |
| 511 | 3 | 5/16-18 Special Nuts | Cutter Bar Stud |
| 513 | 4 | 8/32 x 1/2 R.H.M.S. | Carburetor Strut |
| 514 | 1 | 7/16-20 Left Hand Nut | Manual Pulley |
| 515 | 1 | 7/16-20 Nut | Crankshaft |
| 516 | 18 | 1/4-28 Hex. Steel Nuts | Cyl. Head, Cyl. Block, etc. |
| 517 | 9 | 8/32 Hex. Steel Nuts | Chain Case |
| 518 | 2 | 12/24 x 1 R.H.M.S. | Magneto |
| 519 | 1 | 5/16 SAE Lock Washer | Chain Tightener |

ALL PRICES F.O.B. VANCOUVER, B.C.

| Part No. | Qty. | Description | Position |
|----------|------|----------------------------|-----------------------------|
| 520 | 3 | 5/16 SAE Plain Washer | Felling Handle |
| 521 | 8 | 1/4 SAE Plain Washer | Cyl. Block, Cyl. Head, etc. |
| 522 | 1 | 7/16 SAE Plain Washer | Crankshaft |
| 524 | 25 | 1/4 Shakeproof Washer | Gas Tank, Crankcase, etc. |
| 525 | 13 | No. 8 Shakeproof Washer | Chain Case |
| 528 | 3 | No. 304 Woodruff Key | Spline and 15T Sprocket |
| 529 | 11 | 3/32 x 1/2 Cotter Pin | |
| 532 | 4 | 5/16-24 S.F. Jam Nut | Clutch Stud |
| 535 | 1 | Special Magneto Key | |
| 537 | 2 | 6/32 x 1/2 R.H.M.S. | Reed Valve |
| 538 | 1 | 1/4-20 x 3/8 H.H.C.S. | Drain Plug |
| 539 | 1 | 1/4 Fibre Washer | Drain Plug |
| 540 | 2 | 1/4-20 x 1/2 R.H.M.S. | Control Handle |
| 541 | 1 | 12/24 Hex. Nut | Exhaust |
| 542 | 2 | 1/4-20 x 1/2 F.H.M.S. | Filing Vice |
| 543 | 3 | 5/16-18 x 3/8 F.H.M.S. | Filing Vice |
| 544 | 2 | 1/4-20 x 1 Allen Head C.S. | Gauges |
| 545 | 2 | 1/4-20 Hex. Nut | |
| 546 | 2 | 5/16-18 x 1 H.H.C.S. | Outer End Handle |
| 547 | 2 | 5/16-18 Hex. Nuts | Outer End Handle |
| D-548 | 3 | 8/32 x 3/8 R.H.M.S. | Breather |
| D-549 | 5 | 1/4 SAE Plain Washer | Cyl. Head, Clutch Rod |
| D-550 | 1 | 3/16 Cup Washers | Choke Plate |
| D-551 | 1 | 3/16 x 1/4 R.H. Rivet | Choke Plate |
| D-552 | 4 | 1/16 x 3/8 Cotter Pin | Clutch |
| D-553 | 1 | 3/4-16 NF Jam Nut | Clutch |
| D-554 | 4 | 1/4-28 Castellated Nuts | Clutch |
| D-555 | 2 | 3/32 x 3/4 Cotter Pin | Filing Vice |
| D-556 | 2 | 6/32 x 3/8 R.H.M.S. | Retainer Bar |

PARTS LIST

For P.M. WOODBOSS Power Chain Saw
Manufactured by Power Machinery Limited

| Part No. | Qty. | Description |
|----------|------|----------------------|
| A-101 | 1 | Crankshaft |
| A-102 | 1 | Cylinder Block |
| A-103 | 1 | Piston |
| 104 | 1 | Connecting Rod |
| D-105 | 1 | Crankcase |
| D-106 | 1 | Chain Cover |
| D-107 | 1 | Crankcase Cover |
| A-108 | 1 | Small Sprocket, 15T |
| D-109 | 1 | Large Sprocket, 45T |
| D-110 | 1 | Clutch Spline |
| D-111 | 1 | Sprocket Shaft |
| D-112 | 1 | Pressure Plate |
| 113 | 7 | Small Clutch Plate |
| 114 | 8 | Large Clutch Plate |
| D-115 | 2 | Triangular Toggle |
| D-116 | 2 | Curved Toggle |
| D-117 | 1 | Clutch Fork |
| D-118 | 1 | Clutch Housing Cover |
| D-119 | 1 | Clutch Toggle Pin |
| No. 120 | 1 | Oil Pump Spring |
| D-121 | 4 | Clutch Spring |

| Part No. | Qty. | Description |
|----------|------|--|
| A-122 | 1 | Cylinder Head |
| D-123 | 1 | Breather and Choke Body |
| D-124 | 1 | Exhaust |
| D-125 | 1 | Blower Housing |
| D-126 | 1 | Gasoline Tank |
| 127/14" | | Guide Bar |
| 127/20" | | Guide Bar |
| 127/26" | | Guide Bar |
| 127/32" | | Guide Bar |
| 128 | 1 | Carburetor Adaptor |
| 129 | 1 | Swivel Collar |
| 131 | 2 | Short Crankcase Stud |
| 132 | 1 | Intake Valve |
| 133 | 1 | Intake Valve Spring |
| D-134 | 1 | Breather Screen |
| 135 | 2 | Breather and Crankcase Screen |
| 136 | | Connecting Link |
| 137 | | Right Cutter |
| 138 | | Left Cutter |
| 139 | | Check Valve |
| 140 | | Rakers—Left Raker, Right Raker, Centre |
| 141 | 1 | Pump Plungers |
| 142 | 1 | Plunger Rod |
| A-143 | 1 | Cylinder Block Gasket |
| 144 | 1 | Small Conrod Bushing |
| 145 | 1 | Large Conrod Bushing |
| 146 | 1 | Carburetor Gasket |
| 147 | 1 | Combination Nut |
| 148 | 1 | Starting Pulley (Manual) |
| 150 | 3 | Intake Valve Pins |
| 151 | 1 | Intake Valve Gaskets |
| 152 | 1 | Oil Pump Cylinder |
| 153 | 1 | Cutting Chain Sprocket |
| 155 | 1 | Chain Tightener |
| D-156 | 1 | Handle Bars |
| D-157 | 1 | Throttle Lever |
| 158 | 2 | Crankcase Clip Ring |
| D-159 | 1 | Throttle Rod |
| 160 | 1 | Strut and Oil Tank Sub-assembly |
| D-161 | 1 | Upper Control Grip |
| 162 | 1 | Felling Handle |
| D-163 | 1 | Clutch Control Rod |
| A-164 | 1 | Short Grease Seal Bushing |
| 165 | 1 | Wrist Pin |
| 166 | 2 | Gas and Oil Tank Cap |
| 167 | | Chain Rivets (Per Dozen) |
| 168 | 1 | Fan Cover |
| D-169 | 1 | Clutch Toggle Pin |
| A-170 | 1 | Long Grease Seal Bushing |
| 171 | 3 | Guide Bar Studs |
| D-172 | 1 | Clutch Fork Rivet |
| D-173 | 1 | Clutch Toggle Rivet |
| 174 | 4 | Cylinder Block Studs |
| 175 | 2 | Long Crankcase Bolt |
| D-177 | 1 | Oil Pump Cap |
| 178 | 2 | Wrist Pin Clip Rings |
| 179 | 1 | Throttle Spring |
| D-180 | 1 | Choke Plate |

| Part No. | Qty. | Description |
|--------------------|------|-----------------------------------|
| D-181 | 1 | Breather Cover |
| 183 | 4 | Clutch Stud |
| 184 | 1 | Oil Pump Knob |
| 185 | 1 | Swivel Collar Stud |
| 186/14" | | Cutting Chain |
| 186/20" | | Cutting Chain |
| 186/26" | | Cutting Chain |
| 186/32" | | Cutting Chain |
| 187 | 1 | Spring Washer for Cam |
| 188 | 1 | Sawdust Raker |
| D-190 | 1 | Lower Control Grip |
| 191 | 1 | Clutch Connecting Rod |
| 192 | 2 | Oil Tank Plug |
| 193 | 2 | Carburetor Stud |
| 196 | 1 | Throttle Lever Washer |
| 197 | 1 | Spring Retainer Bar |
| A-198 | 1 | Cylinder Head Gasket |
| 199 | 1 | Crankcase Gasket |
| D-213 | 1 | Snowshoe |
| 218 | 1 | Oil Tank Spring |
| 219 | 2 | Connecting Rod Washers |
| 224 | 1 | Exhaust Stud |
| A-225 | 4 | Cylinder Head Studs |
| D-226 | 1 | Thrust Bearing Retainer |
| D-227 | 1 | Locking Washer for Clutch Nut |
| D-228 | 4 | Clutch Spring Stud |
| D-229 | 1 | Carburetor Spring |
| 250 | 1 | Magneto Complete |
| 251 | 1 | Carburetor |
| 252 | 1 | Spark Plug |
| 253 | 2 | Oil and Compression Seal |
| 254 | 1 | 201 KDD Bearings (Sprocket Shaft) |
| 255 | 5 | 203 KDD Bearings |
| A-256 | 3 | Piston Rings |
| A-257 | 1 | Roller Chain |
| 258 | 1 | Fuel Line |
| 259 | 1 | High Tension Wire and Terminal |
| 260 | 1 | Copper Mesh |
| 261 | 1 | Starting Rope and Handle |
| 263 | 1 | Spark Plug Nipple |
| 266 | 1 | Shut-off Cock |
| D-268 | 1 | Thrust Bearing (ATB 2610) |
| 270 | 1 | Rubber Grommet |
| 271 | 1 | Roller Chain Connecting Link |
| 272 | 1 | Clip for High Tension Wire |
| 273 | 1 | Shorting Button |
| 274/5 | 1 | Shorting Wire and Terminal |
| 508 | 2 | Connecting Rod Screw |
| 511 | 3 | Cutter Bar Nuts |
| Accessories | | |
| 200 | | Filing Vice |
| 203 | 2 | Tightening Stud |
| 205 | 1 | Raker Gauge |
| 206 | 1 | Cutter Gauge |
| 207 | 2 | Filing Vice Handles |
| 209 | 1 | 015 Feeler Gauge |
| 222 | 1 | Setting Block Assembly |
| 211 | 1 | Outer End Handle (Accessory) |
| | | Magneto Timer |

WOODBOS MODEL "D" STARTER

| Part No. | Description |
|----------|---|
| 10380 | Starter Complete |
| 10381 | Starter Back Plate |
| 10382 | Starter Centre Piece |
| 10383 | Starter Cover |
| 10384 | Drive Plate Assembly |
| 10384A | Drive Plate |
| 10384B | Drive Plate Spacer |
| 10385 | Drive Sleeve |
| 10386 | Drive Spring |
| 10387 | Drive Spring Ratchet |
| 10388 | Pulley Complete |
| 10389 | Pulley |
| 10390 | Pulley Hub |
| 10392 | Starter Shaft |
| 10397 | Return Spring |
| 10398 | Locking Nut |
| 12354 | Drive Plate Pins |
| 12355 | Drive Plate Spring |
| 12356 | Drive Plate Pawls |
| 12357 | Pawl Stop Pins |
| 12359 | Drive Sleeve Bushing |
| 12365 | Pulley Hub Pawl Spring |
| 12367 | Pawl Support Ring |
| 12369 | Thrust Washer |
| 13370 | Starting Cable Tube |
| 13371 | Handle Stop |
| 10310 | Starting Cable |
| 10311 | Handle |
| 10318 | Cable Terminal |
| 10303 | Pulley Hub Pawls |
| 10307 | Pawl Pins |
| | HARDWARE |
| 13352 | #6 SAE Flat Washer |
| 10394 | $\frac{1}{8}$ x $\frac{1}{8}$ FH Rivets |
| 10395 | 12-24x2" RHMS |
| 10515 | $\frac{1}{8}$ -20 Nut |
| 10522 | $\frac{1}{8}$ SAE Flat Washer |
| 10528 | #304 Woodruff Key |
| 10314 | 12-24x $\frac{1}{2}$ FHMS |
| 10312 | $\frac{1}{8}$ x $\frac{1}{8}$ RH Rivet |
| 10326 | $\frac{1}{8}$ Countersunk |
| | Shakeproof Washer |
| 13117 | #12 Lock Washer |



MOUNTING INSTRUCTIONS

Make Reference to Diagram


1. Remove existing starter.
2. This Starter is now completely assembled and must be partly dismantled before it can be mounted on the motor. Remove the Starter Backplate (No. 10381) by taking out the three Starter Body screws (No. 10395). Be careful to

keep the Centre Piece (No. 10382) and Starter Cover (No. 10383) from separating. If the Backplate is tight, gently tap it until it becomes free.

3. Fasten Starter Backplate (No. 10381) to the Crankcase Cover with the 4 mounting screws and washers (No. 10314 and No. 10326). Thoroughly tighten. Be sure the Woodruff Key is properly in place. Place the Drive Plate (10384) with a Spacer in front and back on the Crankshaft with the Pawls facing out. The Chamfer on the outer Spacer must face the Drive Plate. Lock securely with the Locking Nut, No. 10398, (Left Hand). Be careful not to break the flywheel fins when locking the Crankshaft.
4. Replace outer assembly on Backplate by locating it on the spigot. Do not force it into place, but pull on the Starter Cable until the Drive Sleeve Ratchet (No. 10385) engages with the Driveplate Pawls, then push into place. Secure with screws.
5. For Dismantling, reverse the foregoing procedure.
6. To Replace Starting Cable (No. 10310). Remove the outer unit from the Starter Backplate—see paragraph (2). Rotate Centre Piece (No. 10382) and Starter Cover (No. 10381) to relieve Return Spring tension on Starter Cable. If cable has broken, rotating is not necessary. Separate the outer unit by holding the outer rim of the Centre Piece and tapping the Drive Sleeve Ratchet with a soft hammer or equivalent. Do not damage bushing. Slip Centre Piece off Spring. Remove old cable and replace with new one. Do not tie the handle in place before threading cable through stem of outer cover. Be sure Cable Ferrule is pushed through cutout in pulley so it will not interfere with spring action. Rewind Return Spring, if it is out of place, slip end of spring into slot in Centre Piece, revolve Centre Piece and Cover until there is tension on the Cable and remount on Backplate.
7. To dismantle, remove the three fastening screws from Starter Cover and the nut (No. 10515) and washer (No. 10522) from the end of starter shaft (No. 10392). Tap apart with a soft hammer or equivalent.
8. To assemble outer unit, place Drive Spring Ratchet (No. 10387) in position on pulley. Put the Starter Shaft and Drive Sleeve (No. 10385) assemble (Drive Sleeve, Drive Spring, and Starter Shaft) through from the other end make sure the Woodruff Key is in place and put on Washer (No. 12369). Hold this assembly by Drive Sleeve Ratchet end and fit cover onto shaft, rotating the cover until Woodruff Key locates. When located, push shaft into position, and replace nuts and washer.



Assembly of Connecting-rod with crankshaft. Notice the position of the small slope of Piston dome is **opposite** the exhaust side of the machine. Rings are put in place later. Be careful not to bend the connecting-rod. (See Connecting-rod instructions.)



Tightening Cylinder head. Whenever a new gasket is put under a cylinder head, re-tighten after the motor has run half an hour or so.


This illustration shows the undercut being made. Notice the operator being made. Notice the operator has made the top cut first. His grip has been transferred from the felling handle to the bucking handle after the cut has been well started.




Chipping out the undercut. Notice the shape of the axe. The back cut in which the saw now rests has been started before chipping out the undercut. The saw is in "ready" position to complete felling the tree.

This illustration shows how to hold the machine to have it in the felling position when it is picked up. See "Felling Instruction."










COVER

MAGNETO FLYWHEEL

D-125 BLOWER HOUSING







MANUFACTURED BY

Power Machinery Limited
VANCOUVER, CANADA



SOLD AND DISTRIBUTED BY

(Canada)

P.M. PRODUCTS (1947) LTD.

895 EAST HASTINGS ST.
VANCOUVER 4, B. C.

(United States)

WOODBOSS INC.

1800 S. E. UNION
PORTLAND 14, ORE.