

This product embodying years of experience in chain saw manufacture incorporates the ultimate in rugged dependability, perfect balance, and continuous power output.

The Pioneer

Power Chain Saw

I.E.L. Power Chain Saws are proudly offered by the owners who work at the benches, lathes, and desks.

Any criticism, comments or suggestions that users care to offer will be most sincerely appreciated in the spirit of co-operation.

There's an I.E.L. Chain Saw to suit every application. Write direct, or see the dealer in your vicinity for information and pamphlets on I.E.L.'s other great models.

8 B.H.P.

INDUSTRIAL ENGINEERING LIMITED

503 East Pender Street

Vancouver, Canada

Phone: HAstings 1760-Wires and Cables-I.E.L.

ALWAYS Specify Machine Model and Serial Number When Ordering Spare Parts

Specifications

Type-Two-cycle, aircooled, single cylinder.

Bore and Stroke — 2.83 inches bore, 2.83 inches stroke.

Horsepower-8 H.P. at 3200 RPM.

Magneto-Eisemann, Model AM2N-2.

Carburetor — Specially manufactured I.E.L. model.

Crankshaft — Alloy steel, heat-treated and precision ground.

Connecting-rod — Alloy steel drop forging, heat-treated and ground.

Piston—Permanent mold, special alloy, heattreated. Wrist-pin—Case-hardened alloy steel, ground.

Main bearings — Four large capacity ball races.

Connecting-rod bearing — Needle roller at bottom, bronze bush at top, heat-treated

Cylinder — Cast iron alloy heat-treated, machined ports. Bore—precision honed.

Cylinder head-Alluminum alloy.

Reduction gear — Heat-treated alloy steel bevel drive.

Clutch — Seven plate dry clutch, asbestos lined.

GUARANTEE:

All machines are guaranteed for thirty days against defective parts, provided our recommendation regarding lubrication and general operation are observed.

Instructions

For the Operation and Care of I.E.L. Model "M" Power Saw


IMPORTANT—The lubrication of this engine is supplied by mixing lubricating oil with the gasoline. This is the only source of lubrication, and trouble is certain if the machine is run on gasoline alone.


PREPARATION FOR STARTING:

The tank should be filled with a mixture of high-grade (70 octane) gasoline and S.A.E. 50 or 60 lubricating oil, in the proportions of eight parts of gasoline to one part of oil when the motor is new. This can be decreased to a twelve to one mix when the motor is broken in.

The gasoline and oil should be mixed in a separate clean container, and must be well stirred with a paddle for thorough mixing. Extra care must be taken in cold weather when the oil is thick and hard to mix.


Always shake the mixture well before pouring into the tank of the engine.






ENGINE ASSEMBLY


B 34	Spark plug cover	К 3	Gasket	K 9A	Bushings
B 132	Locknut for F 34	K 8	Crankshaft pin	K 15A	Lock ring
F 3	Plug	K 9A	Bronze wrist-pin bushing	K 7A	Outer race
F 6B	Retaining screw for conrod	000000000000000000000000000000000000000	in K 6 (2 required)	F 6B	Retaining Screw
	bearing	K 10	Bearing in K 20	2000	
F 7	Inner bearing race	K 14A	Wrist pin	L 27	Idling gear complete with
F7A	Outer race	K 15A	Lock ring for wrist pin	1000 1000	bearing
F11A	Grease seal (3 required)	K 20	End bearing housing with	L 33	Key for fan
F 12	Bearing (2 required)	37878025	studs	11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
F 15	Bearing spacer	K 20D	Retaining ring in K 20	MA8	Crankshaft pinion end as-
F 16	Bearing	K 23	Shims for pinion (assorted	3000 SECTION 1	sembly
F 23A	Exhaust (K 33A1 Exhaust	2000-2007	thicknesses)	M 8	Crankshaft Pinion End
	with clip)	K 24	Pinion nut	F7	Inner race
F 29	Spark plug	K 24A	Pinion washer	K 8	Crankshaft pin
F 30	Timing gear	K 26	Base gasket	150000	
F 31	Timing gear on magneto	K 32A	Intake screen	MA 11	Crankshaft assembly com-
F 34	Bolt for idling gear	K 34	Gasket for exhaust and		plete with connecting rod
F 34A	Nut and washer assembly		carburetor manifold (4 re-	MA 12	Ignition wire assembly
	for F 34		quired)	M 14	Piston
F 51	Magneto adapter	K 36	Cylinder head gasket	M 16	Piston rings (3 required)
F 52	Magneto (Eisemann AM	K 145	Studs	M 21	Pinion (sold only with MA
	2N2)	K 146	Stud		90 Crown and pinion set
F 55	Magneto cover	K 150S	Stud	M 22	Key for pinion
F 55C	Stop button	L 1	Crankcase	MA 25	Cylinder block complete
F 69	Threaded locking ring	L 4	Timing gear cover		with studs
F 70	Spacer for fan	L 9	Crankshaft fan end	M 27	Bi-pass covers (2 required)
F 121	Stud			M 31R	Intake manifold
F 126	Timing gear key	L 10	Connecting rod assembly	M 35	Cylinder head
F 155	Magneto bolt (2 required)	K 6	Con rod (less bearing)	M 150	Intake stud (2 required)






I. E. L. CARBURETOR Part No. K 29R


F 47R	Air filter
K 29R-1	Carburetor bowl
K 29R-2	Top for bowl
K 29R-3	Primer pin
K 29R-4	Primer pin spring
K 29R-5	Primer pin clip
K 29R-6	Float
K 29R-7	Needle valve in float
K 29R-7A	Clip for needle valve (2 required)
K 29R-8	Seat for needle valve
K 29R-9	Fibre washer for K 29 R-8
K 29R-10	Main body assembly
K 29R-11	Top for main casting
K 29R-12	Lock ring for K 29R-11
K 29R-13	Bowden casing adjust- ment screw
K 29R-14	Sliding throttle valve
K 29R-15	Spring for throttle valve
K 29R-16	Guiding screw and nut for throttle slide
K 29R-17	Adjusting screw and nut
K 29R-18	Needle valve for mixer
K 29R-19	Clip for needle valve
K 29R-20	Main mixer (sold only as assembled in K 29R- 10)
K 29R-21	Mixer
K 29R-22	Bolt with screen
K 29R-23	Fibre washer (2 required)
K 29R-24	High speed jet
K 29R-25-1	Main body adjuster
	Fibre gasket
K 29R-25-3	Adjustment nut
K 29R-25-4	K 29R-25-3
K 29R-25-5	speed jet
K 29R-26	Idling jet
K 29R-27	Air valve for idling jet
K 29R-28	Spring for air valve
K 29R-29	Clamp




GEAR HOUSING ASSEMBLY

F 12	Bearing	K 83	Strut only	K 109	Pressure plate next to
F 16	Bearing	K 83A	Strut complete with bolts,		clutch screw
F 86	Thrust bearing		nuts and washers	K 110	Pressure plate fitting into
F 135	Shim	K 84	Gear shaft	Characteristics	gear shaft
K 3	Gasket	K 85	Spindle bolt	K 112	Clutch release screw
K 52A-6		K 85A	Felt washer (4 required)	K 112A	Clutch release spring
K 60	Elbow	K 85B	Spindle bolt spring	K 113	Control lever
K 70	Bowden adjusting screw	K 87	Seat for clutch spring, in-	K 115	Special bolt
K 74	Gear housing		ner	K 115A	Special nut (2 required)
K 76	Filler plug with vent hole	K 78A	Seat for clutch spring,	K 156	Allan head cap screw (8
K 77A	Slotted collar		outer		required)
K 78	Holding ring	K 88	Long key	K 158	Bolts for K 80 (4 required)
K 78A	Paper shims	K 89	Clutch spring	L 35	Throw handle
K 80	End cover complete with	K 91	Key for crown gear	M 90	Crown gear only, sold only
	holts, nuts and washers	K 93	Steel washer		with MA 90 Crown pinion
K 80A	End cover only	K 93A	Felt washer		gear set
K 81	Special bolt for strut	K 94	Spacer	MA 90	Crown gear and pinion,
K 81A	Special washer for K 81	K 94A	Felt washer		sold in sets only
K 82	Special bolt for strut	K 108	Thrust bearing housing		






B 43D	Oil pump knob	F 43E-8	Large leather washer	L 34	Clip
B 43M	Screw	F 43E-9	Nut for pump barrel	L 5	Fan
B 66	Gasket	F 43E-10	. [[[[[[]]]]][[[]]][[[]][[]][[]][[]][[][[L 6	Starting pulley
B 69	Shut off cock	F 43G		M 7	Fan cover
B 70	Adapter with screen	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Cap for oil compartment	M 28	Studs (4 required)
F 42	Gasket	F 44	Gas tank cap	MA2	Fan housing with studs
F 43E	Oil pump complete	F 50A	Shut off cock	M 3A	Gas tank
F 43E-2	Plunger	K 51	Left hand jamb nuts	MA3	Gas tank assembly (com-
F 43E-1	Pump barrel	K 52A-6	Reducer bushing	55655-376-57	plete)
F 43E-3	Leather packing	K 57			
F 43E-4	Plunger rod	100000000000000000000000000000000000000	Gas line	E	xtra Parts Supplied
F 43E-5	Plunger spring	K 58	Oil line	F 29W	Plug Wrench
F 43E-6	Plunger gland	K 60	Elbow	K 62B	Starting Rope
F 43E-7	Small leather washer	K 150L	Stud (4 required)	(Rop	e supplied by the foot.)



HANDLEBARS AND CONTROLS

F 99F	Seat for Bowden casing	F 106	Clutch lever	MA 44	Swivel release assembly
F 101	L. H. grip with catch	F 107	Clutch Bowden wire. (Bowden wire is avail-	M 45	complete Swivel lever bracket
7 101A	Catch for F 106		able by the foot on re-	200000000	
7 101B	Spring for F 101A		quest)	M 46	Bowden adjusting screw
101C	L.H. grip only	F 107A		M 79	Stop pin
	-, 8	1 1 7 1 7 1 7 1 7 1 7 1 7 1 7 1	Nipple	MA 79	Stop pin assembly
F 102	Throttle control assem- bly complete,	F 108	Clutch Bowden wire cas- ing	M 92	Bowden wire and pin as- sembly. (Bowden wire
102A	Throttle lever bracket		Pin for clutch lever		is available by the foot
7 102B	Throttle lever arm	K 79D	Stop pin spring		on request)
F 102C	Brass swivel on throttle lever	L 26 L 31R	Right hand grip Throttle control wire	M 82A M 83	Stop pin spindle Spindle guide
102D	Special bolt for throttle lever assembly and	L 32R	Throttle wire Bowden casing	M 84	Retaining nut
	swivel lever assembly	M Group 1	Handle bars complete	M 86	Swivel Bowden casing
102E	Special brass washer		with grips	MA 125	Handle bars welded as-
	Special Stand Wallet	M 44	Swivel lever handle	ATTACK A MANUE	sembly



OU'	TER END ASSEMBLY
LA 37	Outer End Assembly
	11 gauge
FA 195	Outer End Assembly
	14 gauge
	(For FL type cutter bar
	only)
GA 195	Outer End Assembly
	14 gauge
F 174	Main body casting 14
	gauge complete with
	inspection door
F 174A	Inspection door
F 190	Tail stock spring
F 195	Handle and tightening
	screw
F 197	Tail stock handle
F 199	Fork
F 202	Idler pin
F 204	Idler spacer (2 required)
F 206	14 gauge Idler (for FL
	type bar only)

F I	70
F 207	11 gauge Idler
F 210	Tail stock bearing (2 required)
F 211	Retaining ring for F 210
G 206	14 gauge Idler
HJC 8	1/2" Jam nut for F 202 (2 required)
K 134	Butter bar guide
L 36	Main body casting 11 gauge complete with inspection door
L 160	Special bolt for K 134
SPW 10	Special spacer washer for shimming F 210
	CHAINS
Chaine	are supplied in 11 or 14

Chains are supplied in 11 or 14 gauge sizes, length specified being that of the cutter bar used. Length to be specified in feet. CC 11 11 gauge chain CC 11A 11 gauge "A" type chain

CC 14A 14 gauge chain "A" type

CHAIN PARTS

When ordering Chain parts the number is as listed below-Specify the gauge e.g.: cc 137-11 is an 11 gauge side link.

CC 137 Side links CC 138 Right side cutter CC 139 Left side cutter CC 140 Right raker CC 141 Left raker CC 142 Centre raker CC 143 Master side cutter CC 144 CC 162 Master side links Dud - used on "A" type chain only F 170 14 gauge rivets F 171 14 gauge master rivets K 135 11 gauge rivets

K 136 11 gauge master rivets